

**NOTE:** The assembly of the S4™ host is identical to that of the standard C6 host, only the parts look slightly different. There is also an o-ring that is seated between the bezel/retaining ring and the heat sink. **Do not lose this o-ring.** In addition, **please pay special attention to not letting the heat sink rotate while you tighten the bezel/retaining ring, or the diode wires may twist and break.** Apply pressure with your finger to the exposed surface of the heat sink to prevent it from rotating while you tighten the bezel/retaining ring.

**NOTE:** The assembly of the S4™ host is identical to that of the standard C6 host, only the parts look slightly different. There is also an o-ring that is seated between the bezel/retaining ring and the heat sink. **Do not lose this o-ring.** In addition, **please pay special attention to not letting the heat sink rotate while you tighten the bezel/retaining ring, or the diode wires may twist and break.** Apply pressure with your finger to the exposed surface of the heat sink to prevent it from rotating while you tighten the bezel/retaining ring.

**NOTE:** The assembly of the S4™ host is identical to that of the standard C6 host, only the parts look slightly different. There is also an o-ring that is seated between the bezel/retaining ring and the heat sink. **Do not lose this o-ring.** In addition, **please pay special attention to not letting the heat sink rotate while you tighten the bezel/retaining ring, or the diode wires may twist and break.** Apply pressure with your finger to the exposed surface of the heat sink to prevent it from rotating while you tighten the bezel/retaining ring.